


C



— Gris blanc Rose 2
 — Bleu Rose 1

Viole
 Jasne x Orange 2
 Fushia x Or 2

	IT	FR	ES	DE
KEYS	TASTI PROGRAMMAZIONE E COMANDO	TOUCHES DE PROGRAMMATION ET COMMANDE	TECLAS DE PROGRAMACION Y MANDO	PROGRAMMIER- UND BEFEHLSSTASTEN
FLASH	LAMPEGGIANTE	CLIGNOTANT	INTERMITENTE	BLINKLEUCHTE
TX - RX	FOTOCELLULE	PHOTOCELLULES	FOTOCÉLULAS	FOTOZELLEN
NO - NC - BK2	INGRESSO BORDO SENSIBILE	FR	ES	DE
FUSE	FUSIBILE	FUSIBLE	FUSIBLE	SICHERUNG
AERIAL	ANTENNA	ANTENNE	ANTENNA	ANTENNE
LED	LED FUNZIONI	LED DE FONCTIONS	LED FUNCIONES	FUNKTIONSANZEIGEL-LED

7.

IT	controller
EN	check; check
FR	contrôler; rac
ES	controlar; con
DE	Überprüfen S
PL	sprawdzić po
NL	controleren; e
RU	проверит

• IT - LEGENDA •
 УСПОБНЫЕ ОБС

ON

OFF